

## **EN** Operating Instructions for Solight WN49



**Battery:** 3.7V 400mAh Li-Ion

**Input:** USB-C

**Battery life min./max.:** 1h/2h

**Charging time:** 2hrs

**Number of light modes:** 3 - 100% front, intermittent (flashing) front, 100% side

**Coverage:** IP44

**Charging:** plug the flashlight into a USB socket on your computer or a USB charging adapter. When charging, the red LED light will illuminate, once the flashlight is charged, the light will turn off.

The flashlight has an **adjustable light cone** (zoom). Change by pulling and retracting the head of the flashlight.

**The light modes** are switched by a button on the top of the flashlight, next to the USB input.

The light source of this luminaire is non-replaceable, at the end of its service life the entire luminaire must be replaced and disposed of in a designated place.

**Manufacturer:** Solight Holding, s.r.o., Na Brně 1972, Hradec Králové 500 06, Czech Republic